

# GOLDAIR

## Juicer

Model FJE400W

### OPERATING INSTRUCTIONS



FJE400W: 220-240V ~, 50Hz, 700W

■

Thank you for choosing this Goldair juicer. This Goldair appliance has been designed and manufactured to the highest of standards and with proper use and care, as described in this leaflet, it will give you years of useful service. Please read these instructions carefully.

## GENERAL CARE AND SAFETY GUIDE

Please read all instructions carefully before using this appliance and keep them for future reference.

### ALWAYS

- ✓ Always ensure hands are dry before handling the plug or switching on the Juicer.
- ✓ Always use the Juicer on a secure, dry, level surface.
- ✓ Always disconnect the blender from the supply if it is left unattended and before assembling, disassembling or cleaning.
- ✓ Carry out regular checks of the supply cord to ensure no damage is evident.
- ✓ Take care when handling the sharp cutting blades while emptying the bowl and during cleaning.

### NEVER


- ✗ Never use this appliance outdoors.
- ✗ Never use this appliance for any purpose other than its intended use. This appliance is for household use only.
- ✗ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they are supervised or have been given instruction concerning the use of the Juicer by a person responsible for their safety.
- ✗ Close supervision is necessary when the appliance is near children.
- ✗ Never place this appliance on or near a hot gas or electric burner or where it could touch a heated oven or microwave oven.
- ✗ Never use harsh, abrasive or caustic cleaners to clean this appliance.
- ✗ Never operate the appliance with a damaged cord or plug, after it malfunctions, or if it has been damaged in any manner.
- ✗ The Juicer is not intended to be operated by means of an external timer or separate remote-control system.

# GOLDAIR

### SUPPORT AND TECHNICAL ADVICE

North Shore City, Auckland, New Zealand  
Monday – Friday 8am-5pm  
Phone: 0800 232 633  
Website: [www.goldair.co.nz](http://www.goldair.co.nz)

# COMPONENTS



## TIPS FOR JUICING

The juice from fresh fruit and vegetables is high in nutritional content. Juice from fresh fruit and vegetables is an important part of a balanced diet.

When selecting fruit and vegetables for juicing, always select fresh and well ripened specimens. Fresh fruit and vegetables carry more flavour and juice than those that are not properly ripened.

Juice is best consumed when freshly made as this is when its vitamin and mineral content is highest.

Your juicer can handle most varieties of fruit and vegetables. If using fruit with hard, inedible skin (i.e. watermelons, pineapple, mangoes etc.) always peel the skin before placing in the juicer.

The skin of citrus fruit should also be removed before fruit is placed in the juicer. For better tasting citrus juice, also remove the inner white peel from the fruit. Fruits with stones or hard seeds (i.e. mangoes, nectarines, apricots, and cherries) should be pitted before juicing.

A small amount of lemon can be added to apple juice to prevent the juice browning.

Banana's can be difficult to juice, if using banana add it as the first or second ingredient, the nectar of the banana will flow through into the juice created from the other fruits.

The juicer is not suitable for juicing very hard and starchy fruits or vegetables such as sugar cane. When juicing fruit and vegetables of different consistency it may help to juice different combinations, i.e. juice soft fruit first, (i.e. oranges) then follow with hard fruit (i.e. apples). This will help you achieve maximum juice extraction. If juicing herbs or leafy vegetables, wrap them together to form a bundle before placing in the juicer or combine them with other ingredients on low speed.

# ASSEMBLING YOUR JUICER

- Prior to assembling your juicer, ensure all packaging has been removed.
- We recommend washing all parts except the motor unit in hot soapy water before using the juicer for the first time.
- **IMPORTANT:** Always ensure your juicer is unplugged from the power supply when not in use, while assembling and disassembling.

## STEP 1

Place the filter holder inside the main body so the spout clicks in place on the right hand side.



## STEP 2

Place the filter in position so it locks into the holder and cannot be removed.



## STEP 3

Tilt the pulp bin slightly so it fits in position on the left hand side of the juicer's main body.



## STEP 4

Fit the lid over the juicer main body and the pulp bin.



## STEP 5

Push the safety catch up over the juicer so it locks into a vertical position on top of the juicer lid.



## STEP 6

Place the juice collector in position so the lid of the collector fits over the spout.



## STEP 7

Slide the food pusher down the food chute. The pusher can only fit one way.



**NOTE:** The juicer will only function correctly if all parts have been assembled correctly, the lid is in position and the safety clamp is locked in place.

Do not use the Juicer if the rotating sieve/filter is damaged.

# OPERATING YOUR JUICER

1. Ensure the juicer is turned off.
2. Plug the unit into a 220-240V power outlet and turn the power on at the power outlet.
3. Clean fruit and vegetables thoroughly, ready for juicing.
4. If juicing fruit with stones or hard seeds, pit the fruit. Remove any hard inedible skins, i.e. skin of melons, pineapples and mangoes prior to juicing. If citrus fruits are being used, remove the skin prior to juicing.
5. If pieces of fruit or vegetables are very large, chop them to a size that will fit down the juicer's food chute.
6. Turn the speed control switch to the desired speed setting. Setting 1 is LOW and Setting 2 is HIGH. The lower speed setting is better for soft fruits and vegetables, while the higher speed setting is better for hard fruits and vegetables.
7. Ensure the safety catch is locked in position -vertically on top of the juicer lid.
8. Press the food pusher slowly down until all fruit or vegetables have gone through the juicer. Do not press the food pusher rapidly as the juicer will not be as effective.  
**CAUTION: DO NOT PUT YOUR HAND OR ANY OTHER OBJECT IN THE FOOD CHUTE DURING OPERATION.**
9. The juice from the fruit and/or vegetables will flow directly into the jug and the pulp will be collected in the pulp bin.
10. **IMPORTANT:** While juicing, ensure the pulp bin does not overflow as this can cause damage to the juicer and prevent it functioning correctly.
11. When juicing is complete, ensure that the juicer's control switch is set to the OFF position, the power is turned off at the outlet and the juicer is unplugged.
12. It is now safe to disassemble the unit.
13. Disassemble your juicer in the following order:
  - Remove the pulp bin.
  - Remove the food pusher.
  - Open the safety clamp.
  - Remove the lid.
  - Remove the juice collector.
  - Remove the filter holder & filter.

# CARE AND CLEANING

- Ensure the juicer's control switch is set to the OFF position, the power supply is turned off at the outlet and the juicer is unplugged.
- Disassemble all parts and wash in warm soapy water and dry thoroughly.
- Ensure all pulp is removed from the juicer blade.  
**CAUTION:** Be careful when cleaning or handling the juicer blade as it is very sharp.
- The main body cannot be cleaned with water, wipe clean with a damp cloth.
- The juicer blade should be cleaned carefully after each use.
- Store the juicer in a dry ventilated place if it is not going to be used for a long period of time.
- Please clean the waste container and any residue left in the juicer chute/lid if operating the juicer frequently within a short period of time in order to avoid the motor getting blocked.

# RECIPES

## **Apple, Carrot & Ginger Juice**

3 green apples

3 carrots, greens removed

2cm piece of fresh ginger

Process the ingredients in juicer and serve.

## **Blueberry Grape Juice**

A handful of grapes

1 cup of blueberries, fresh or thawed from frozen

1 peeled grapefruit (optional)

Process the fruit in juicer and serve.

## **Apple Kiwifruit Juice**

3 kiwifruit, peeled

2 apples

Process the fruit in juicer and serve.

## **Pineapple Orange & Strawberry Cocktail**

2 peeled oranges

1 cup of fresh, cubed pineapple, skin removed

6 strawberries

Process the fruit in juicer and serve.

## **Cucumber & Celery Cooler**

3 carrots, greens removed

1/4 medium cucumber, peeled

1 stalk celery, cut into 5cm pieces.

1 apple

1/2 lemon, peeled (optional)

Process the ingredients in juicer and serve.

## **Calcium Drink**

4 carrots, greens removed

1/2 cup of fresh broccoli pieces

2 apples

A small handful of fresh parsley

1/2 lemon, peeled (optional)

Process the ingredients in juicer and serve.

## **Potassium Drink**

4 medium carrots, greens removed

1 apple

1 stalk of celery, cut into 5cm pieces

A small handful of fresh parsley

A small handful of fresh spinach

1/2 lemon, peeled (optional)

Process the ingredients in juicer and serve.

## RECIPES CONTINUED

### **Ginger Ale with Lemon & Lime**

A handful of grapes

2 apples

2cm piece of fresh ginger

1/2 lime

1/4 lemon

sparkling mineral water

Remove the grapes from the stem.

Juice the apple and ginger together, then juice the rest of the fruit.

Pour the juice in a large glass, fill to the top with sparkling water and serve with ice.

### **Sparkling Juice**

2 kiwifruit

1 peeled orange

1/2 mango, skin removed.

sparkling mineral water

Process the fruit in a juicer. Pour the juice in a large glass and fill to the top with sparkling water and serve.

### **Apple Cider with Ginger**

2cm piece of ginger

3 apples

Process in juicer and serve.

### **Peach Pear & Apple Juice**

1 apple

2 pitted peaches

1 pear

Process in juicer and serve.

### **Fruit Punch**

6 strawberries, fresh or thawed

1 apple

1/2 peeled orange

Process the fruit in juicer and serve.

### **Fruit Nectar**

1/2 cup raspberries, fresh or thawed

1 peeled orange

1 pitted nectarine

Process in juicer and serve

### **Tropical Smoothie**

1 apple

3 Apricots

Banana

A teaspoon of spirulina

Process in juicer and serve

# GOLDAIR

Your Goldair product has been inspected and tested and is guaranteed subject to the following for a period to two years from the date of purchase against defects in workmanship and materials. During this period, such defects will be rectified by repair or replacement of the product purchased. Your product contains no user serviceable components and this warranty becomes invalid if in our opinion the product has been misused, abused, incorrectly installed, tampered with, connected to an electrical supply not corresponding with the name plate specification, or subjected to power surges. The warranty does not include any labour or other associated expense that may be involved in removal or installation of the product. Normal wear and tear is expressly excluded.

If your Goldair product fails to operate satisfactorily, please return it to the retailer from whom it was purchased. To obtain a repair or replacement product under this warranty, you will need to produce satisfactory evidence of date of purchase. The completed warranty and purchase receipt must be presented with the product. The warranty should be filled out at the time of purchase. It is in your interest to make sure this is done.

If the product is to be replaced (cannot be repaired) then that replacement will be of the same or similar product or accessory excluding packaging, instruction card etc. Where a replacement product is supplied, this shall be guaranteed for the balance of the original warranty period.

Any model that is no longer available will be replaced by a model of a value and with such features as we consider appropriate in the circumstances. Goldair Ltd is not responsible for freight forwarding charges, losses or damage in transit.

If service is required after the warranty period has expired, the product should be returned to a qualified electrical technician. Service outside of the warranty period will be at your cost.

Consumers Guarantee Act (1993).

In accordance with the above act consumers are advised that: The manufacturer does not undertake that repair facilities and parts are necessarily available for this product.

If any of the provisions of the foregoing are contrary to any relevant legislation, then that provision shall be deemed to be excluded from the warranty and the rest of the provisions will continue to apply.

## IMPORTANT: PLEASE RETAIN THIS WARRANTY CARD

NAME: \_\_\_\_\_

ADDRESS: \_\_\_\_\_

PURCHASED FROM: \_\_\_\_\_

SUBURB: \_\_\_\_\_

DATE OF PURCHASE: \_\_\_\_\_

NAME OF PRODUCT: \_\_\_\_\_

MODEL No: \_\_\_\_\_

**TWO YEAR WARRANTY**