

GOLDAIR

Bench Blender

Model GBB200

OPERATING INSTRUCTIONS



Thank you for choosing this GOLDAIR blender. This GOLDAIR appliance has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, it will give you years of useful service. Please read these instructions carefully.

GENERAL CARE AND SAFETY GUIDE

Please read all instructions carefully before using this appliance and keep them for future reference.


1. Use only the voltage specified on the rating plate.
2. Do not use this appliance on a wet surface, or where it can fall or be pushed into water.
3. Do not reach for an appliance that has fallen into water. Switch off at the power supply and unplug immediately.
4. This blender is intended for household use only and not for commercial or industrial use.
5. The motor must always be switched off before the blender is connected with the mains supply.
6. Keep hands and utensils out of glass jug while blending.
7. The blender is not to be operated while empty (i.e. without solid or liquid foodstuff).
8. Allow any hot liquids to cool to a lukewarm temperature before pouring them into the blending unit.
9. Do not operate the blender for more than 3 minutes at any time.
10. Always operate blender with cover in place.
11. CAUTION: The blades are sharp – handle with care.
12. To reduce the risk of injury never place the blades on the base without the jar properly attached.
13. Ensure the power cord is not left hanging over the edge of a table or benchtop.
14. Avoid contacting moving parts.
15. The use of attachments not recommended or sold by the manufacturer may cause fire, electrical shock or injury.
16. Do not operate the appliance with a damaged cord, plug or after the appliance malfunctions or has been dropped or damaged in any manner. Return to a qualified electrical person for examination, electrical or mechanical adjustment, service or repair.
17. Do not twist, kink or wrap the cord around the appliance, as this may cause the insulation to weaken and split.
18. Do not remove plug from power socket until the appliance has been switched off.
19. Do not remove plug from power socket by pulling flex - always grip plug.
20. Do not allow cord to come in contact with heated surfaces during operation.
21. Use this appliance only as described in this manual. Any other use is not recommended by the manufacturer and may cause electric shock or injury.
22. This appliance is not intended for use by young children or infirm persons unless they have been adequately supervised by a responsible person to ensure that they can use the appliance safely.
23. Young children should be supervised to ensure they do not play with this appliance.
24. Do not use abrasive cleaning products on this appliance. Always remove the plug from the mains supply before cleaning.
25. Do not plug the appliance into the power supply until it is fully assembled and always unplug before disassembling the appliance or handling the blade.

COMPONENTS

1. Measuring cap
2. Jug Lid
3. 1.6L Glass Jug
4. Stainless Steel Blades
5. 600W Motor Unit
6. Speed Setting Control

SPEED SETTINGS

- P = Pulse
0 = Off
1 = Low
2 = High



OPERATING YOUR BLENDER

The Lid is easy to assemble and disassemble for a quick clean up.

1. Insert the measuring cap into the lid and twist either direction to secure it into position.
2. Push the lid down firmly on the jug to seal.
3. Position the jug on the motor unit and lock into place by twisting counter-clockwise.
4. Place ingredients in the jug.
NOTE: Do not operate the blender when empty.
NOTE: Never fill the blender past the maximum mark on the jug.
5. Secure the lid in place.
NOTE: Ensure the lid is in position at all times during operating.
6. Select the desired speed setting, this will remain on until the speed control setting is turned counter-clockwise to the OFF position.
7. The measuring cap can be removed at any time during blending to easily add ingredients.
NOTE: Wait until the blade completely stops before removing the lid or jug.

CARE AND CLEANING

NOTE: First remove the mains plug from the wall socket.

CAUTION: Do not immerse the motor housing in water.

- Clean the motor housing with a soft damp cloth.
- Do not use abrasive cleaning materials.
- Disassemble the other parts after each use and wash them in soapy water. Rinse with clean water and dry thoroughly. Do not wash these parts in a dishwasher.

NOTE: Cleaning is easier when done immediately after use.

- For a quick clean fill the jug with water connect to the motor unit, and select the pulse button several times.