

# GOLDAIR

## Geneva™ Coffee Maker

FCM310

### OPERATING INSTRUCTIONS



**FCM310:** 230-240V ~, 50Hz, 1000-1100W, Geneva Coffee Maker

---

Thank you for choosing a Goldair Electric Coffee Maker . This Goldair appliance has been designed and manufactured to high standards of engineering and with proper use and care, as described in this leaflet, will give you years of useful service. Please read these instructions carefully.

---

## GENERAL CARE AND SAFETY GUIDE

### ALWAYS

- ✓ Always ensure hands are dry before handling the plug or the Coffee Maker .
- ✓ Always operate the Coffee Maker on a secure, dry, level surface.
- ✓ Always allow adequate air space above and on all sides for air circulation. Do not allow the Coffee Maker to touch curtains, wall coverings, clothing, dishtowels or other flammable materials during use. Do not use under cupboards or curtains.
- ✓ Always be sure to unplug from the socket when not in use and before cleaning.
- ✓ Always allow the Coffee Maker to cool before cleaning and storing.
- ✓ Carry out regular checks of the supply cord to ensure no damage is evident.
- ✓ Return the Coffee Maker after a malfunction, or if it has been damaged in any manner to an authorised electrician for examination, repair or adjustment as special purpose tools are required.


### NEVER

- ✗ Never touch hot surfaces.
- ✗ Never use this appliance outdoors.
- ✗ Never use this appliance for any purpose other than its intended use. This appliance is for household use only.
- ✗ This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they are supervised or have been given instruction concerning the use of the Coffee Maker by a person responsible for their safety.
- ✗ Close supervision is necessary when the appliance is near children.
- ✗ Never leave the appliance unattended when in use.
- ✗ Never place this appliance on or near a hot gas or electric burner or where it could touch a heated oven or microwave oven.
- ✗ Never immerse any part of the Coffee Maker , or cord set and plug in water or any other liquid to protect against electrical hazards.
- ✗ Never use harsh, abrasive or caustic cleaners to clean this appliance.
- ✗ Never operate the appliance with a damaged cord or plug, after it malfunctions, or if it has been damaged in any manner.
- ✗ The Coffee Maker is not intended to be operated by means of an external timer or separate remote-control system.

### CAUTION:

THE COFFEE MAKER GENERATES HEAT AND STEAM DURING USE. PROPER PRECAUTIONS MUST BE TAKEN TO PREVENT THE RISK OF BURNS, SCALDS, FIRES OR OTHER DAMAGE TO PERSONS.

## COMPONENTS



## FEATURES

- ★ Automatic cut out boil-dry protection.
- ★ Easy read water gauge.
- ★ High quality thermostat.
- ★ High quality body
- ★ Portable Jug

## BEFORE FIRST USE

1. **REMOVE ALL STICKERS , PACKING MATERIAL, AND LITERATURE.**
2. Wash the coffee glass and lid in hot, sudsy water –rinse thoroughly. These parts are also dishwasher-safe, top rack.
3. Clean the inside of your coffee maker by lifting the Reservoir Lid and pouring cold water into the Reservoir up to (but NOT exceeding) the 8- cup level. Pull open and swing-out the Filter Basket, But DO NOT add coffee grounds. Close the Reservoir Lid.
4. Place the Coffee glass with Lid in the Coffee maker and push “1”. When all the water has brewed through turn the Coffee maker off and discard the water.

## BREWING COFFEE

1. Use the coffee glass to fill the Water Reservoir with cold water. Watch for the desired level in the Water Reservoir. Then close the Reservoir Lid.
2. Pull the swing-out Filter Basket open, place Filter into the Basket, add coffee to the desired level (usually one heaping tablespoon for every two cups – adjust to your taste ),and shake the basket slightly to distribute grounds evenly. Swing the Basket closed and be sure it latches
3. Place the Coffee glass on the “Keeps Hot” plate
4. Push the control to “1”. you do not have to set the clock if you want to brew coffee right away, Simply flip the “1”button and the light will come off.
5. Replace the coffee glass on the “keeps Hot” plate when not serving to keep coffee hot.
6. Flip the control to “0” when finished brewing ,or you may flip the “0” button to instantly turn off the Coffeemaker.

## INTERRUPT FEATURE

The Interrupt feature lets you pour a cup of coffee before brewing is done. There is an automatic drip stop that lets you remove the Coffee glass to “sneak-a cup” without leaking from the filter Basket.

NOTE: The coffee glass must be replaced under the Filter Basket within 30 seconds to prevent the Basket from overflowing.

## REMOVAL OF MINERAL DEPOSITS

Mineral deposits may build up in the water tank after time.  
If the deposits are not removed, the brewing process will take longer than usual.

### TO REMOVE MINERAL DEPOSITS:

- ★ Fill the glass carafe with a mixture of 2/3 water and 1/3 white vinegar.
- ★ Ensure the filter basket is empty.
- ★ Pour the water and vinegar mixture into the water tank.
- ★ Firmly close the water tank lid.
- ★ Place the empty carafe onto the hot plate and press the ON / OFF button so the red light illuminates to indicate BREW mode. The water will start to drip through.
- ★ Once the brewing cycle is complete (indicated by 3 long beeps), turn the Coffee Maker off by pressing the ON / OFF button and carefully dispose of the hot water / vinegar mixture in the carafe.
- ★ Refill the carafe with water. Carefully lift the water tank lid and pour water into the water tank.
- ★ Position the carafe on the hot plate.
- ★ Turn the Coffee Maker on by pressing the ON / OFF button, so the red light illuminates to indicate BREW mode. The water will start to drip through.
- ★ Once the cycle is complete, turn the Coffee Maker off, switch off at the power outlet and unplug.
- ★ Mineral deposits have now been removed from your Coffee Maker.

**CAUTION:** To prevent damage to the appliance, do not use alkaline cleaning agents when cleaning, use a soft cloth and mild detergent.

### ATTENTION:

This appliance is intended to be used in household and similar applications:

- ★ Staff kitchen areas, offices and other working environments;
- ★ Farm houses;
- ★ By clients in hotels, motels and other residential type environments;
- ★ Bed and Breakfast type environments.

# GOLDAIR

### SUPPORT AND TECHNICAL ADVICE

North Shore City, Auckland, New Zealand  
Monday – Friday 8am-5pm  
Phone: 0800 232 633  
Website: [www.goldair.co.nz](http://www.goldair.co.nz)

# GOLDAIR

Your Goldair product has been inspected and tested and is guaranteed subject to the following for a period to two years from the date of purchase against defects in workmanship and materials. During this period, such defects will be rectified by repair or replacement of the product purchased. Your product contains no user serviceable components and this warranty becomes invalid if in our opinion the product has been misused, abused, incorrectly installed, tampered with, connected to an electrical supply not corresponding with the name plate specification, or subjected to power surges. The warranty does not include any labour or other associated expense that may be involved in removal or installation of the product. Normal wear and tear is expressly excluded.

If your Goldair product fails to operate satisfactorily, please return it to the retailer from whom it was purchased. To obtain a repair or replacement product under this warranty, you will need to produce satisfactory evidence of date of purchase. The completed warranty and purchase receipt must be presented with the product. The warranty should be filled out at the time of purchase. It is in your interest to make sure this is done.

If the product is to be replaced (cannot be repaired) then that replacement will be of the same or similar product or accessory excluding packaging, instruction card etc. Where a replacement product is supplied, this shall be guaranteed for the balance of the original warranty period.

Any model that is no longer available will be replaced by a model of a value and with such features as we consider appropriate in the circumstances. Goldair Ltd is not responsible for freight forwarding charges, losses or damage in transit.

If service is required after the warranty period has expired, the product should be returned to a qualified electrical technician. Service outside of the warranty period will be at your cost.

Consumers Guarantee Act (1993).

In accordance with the above act consumers are advised that: The manufacturer does not undertake that repair facilities and parts are necessarily available for this product.

If any of the provisions of the foregoing are contrary to any relevant legislation, then that provision shall be deemed to be excluded from the warranty and the rest of the provisions will continue to apply.

## IMPORTANT: PLEASE RETAIN THIS WARRANTY CARD

NAME: \_\_\_\_\_

ADDRESS: \_\_\_\_\_

PURCHASED FROM: \_\_\_\_\_

SUBURB: \_\_\_\_\_

DATE OF PURCHASE: \_\_\_\_\_

NAME OF PRODUCT: \_\_\_\_\_

MODEL No: \_\_\_\_\_

**TWO YEAR WARRANTY**